

**Wenzhou Amon Electric Co.,Ltd**

<https://www.wzamon.com>

**SWITCH  
SOCKET**





Wenzhou Amon Electric Co.,Ltd

## Company Profile

The company, after years of development, has become a manufacturing, research, trade and services in one of the large modern appliances enterprises. Our products are mainly involved in electrical products, electrical construction, industrial electronics, small appliances, electrical fields, producing wall switches, sockets and other nine series of nearly one thousand kinds of products, the country has eight hundred agents, six thousand sales outlets

In the long-term practice, we advance the concept and action, take the initiative to understand and develop the market and create a brand new marketing new ideas, establish a marketing network covering the whole country, the formation of a strong brand competitiveness.

Strong technical production capacity, with a number of leading domestic technology level of production lines, a senior engineer more than twenty. Through cooperation with the domestic first-class institute, the introduction of advanced equipment, supplemented by imports of high-quality PC materials and exquisite craftsmanship, to create a life, market-leading electrical products.

Companies with strong R D strength, humane management philosophy, to provide consumers with personalized, high quality of life to enjoy. Companies strictly enforce the ISO9001:2000 international quality management system standards, and passed the national compulsory 3C certification, trying to high-quality products and high quality services to enhance the company does not group brand awareness and reputation.

**SWITCH & SOCKET**

**OEM/ODM**



# Content

<b>AM3-C</b> ■ GOLD ■ GRAY ■ BLACK ■ WHITE	<b>01-06</b>	<b>AM4-H</b>	<b>39-40</b>
<b>AM3-A</b> ■ GOLD ■ GRAY ■ BLACK ■ WHITE	<b>07-12</b>	<b>AM4-J</b>	<b>41-42</b>
<b>AM3-B</b> ■ GOLD ■ GRAY ■ BLACK ■ PATTERN	<b>13-16</b>	<b>AM4-S</b>	<b>43-44</b>
<b>AM3-D</b> ■ GOLD ■ GRAY ■ BLACK ■ WHITE	<b>17-20</b>	<b>AM4-F</b>	<b>45-46</b>
<b>AM3-E</b> ■ GOLD ■ GRAY ■ BLACK ■ WHITE	<b>21-26</b>	<b>AM4-E</b>	<b>47-50</b>
<b>AM4-A</b> ■ GOLD ■ WHITE	<b>27-28</b>	<b>AM4-K</b>	<b>51-52</b>
<b>AM4-B</b> ■ WHITE	<b>29-32</b>	<b>AM4-K</b>	<b>52-56</b>
<b>AM4-C</b> ■ GOLD ■ WHITE	<b>33-36</b>	<b>AM4-D</b>	<b>57-58</b>
<b>AM4-D</b>	<b>37-38</b>	<b>面板+功能件</b> <small>(SERIES)</small>	<b>59-60</b>
		■ GOLD ■ GRAY ■ SILVER ■ WHITE	



# SWITCH SOCKET

Provide the global home with great idea and create a beautiful home,  
its electrical accessories not only excellent in function,  
but also add unlimited fun and personalized features for your living space,  
we brought together singularity with inspiration, will create a unique household environment for you.

Wenzhou Amon Electric Co.,Ltd

**1.5°**  
Ultra small swing angle

**2.5mm**  
Ultra-short key travel

**6.5mm**  
The overall thickness

**1.5°**  
Ultra small swing angle

**Ultra Thin**

*The Beauty Of Thinness*

**2.5mm**

**6.5mm**

*Feel the ultra-thin visual enjoyment*

**1.5°**  
Ultra small swing angle

**2.5mm**  
Ultra-short key travel

**6.5mm**  
The overall thickness

**Ultra Thin**

*Perfect touch technological breakthrough*

**Ultra Thin**

**1.5°**  
Ultra small swing angle



**2.5mm**  
Ultra-short key travel

**6.5mm**  
The overall thickness

**Ultra Thin**



### Installation features



Company provide the global home with great idea and create a beautiful home, its electrical accessories not only excellent in function, but also add unlimited fun and personalized features for your living space, we brought together singularity with inspiration, will create a unique household environment for you.



# AM3-C



## Ultra Thin

1.5°

Ultra small swing angle

2.5mm


Ultra-short key travel

6.5mm

The overall thickness

In simple beauty, blooming every inch of living space, product appearance, luxurious atmosphere, combined with modern trend style design. Through high-quality products, materials and refined the production process, so the overall sense of the perfect embodiment of the switch.

Wenzhou Amon Electric Co.,Ltd




Provide the global home with great idea and create a beautiful home, its electrical accessories not only excellent in function, but also add unlimited fun and personalized features for your living space, we brought together singularity with inspiration, will create a unique household environment for you.



# AM3-C

PC Material Panel

Switch socket life Electrical



**AM3-C-1** 1Gang 1 Way Switch  
**AM3-C-1-1** 1Gang 2 Way Switch  
**AM3-C-2** 1Gang 1 Way Switch  
**AM3-C-2-1** 1Gang 2 Way Switch  
**AM3-C-3** 2Gang 1 Way Switch  
**AM3-C-3-1** 2Gang 2 Way Switch  
**AM3-C-4** 3Gang 1 Way Switch  
**AM3-C-4-1** 3Gang 2 Way Switch  
**AM3-C-5** 4Gang 1 Way Switch  
**AM3-C-5-1** 4Gang 2 Way Switch



**AM3-C-6** Door Bell Switch  
**AM3-C-7** 2 Pin Socket  
**AM3-C-8** MF Socket  
**AM3-C-9** 3 Pole Socket  
**AM3-C-10** Thailand 3 Pole Socket



**AM3-C-11** Double 2 Pin Socket  
**AM3-C-12** 8 Pin Socket  
**AM3-C-13** 1Gang 1 Way Switch +Thailand Socket  
**AM3-C-13-1** 1Gang 2 Way Switch +Thailand Socket  
**AM3-C-14** 1Gang 1 Way Switch +3 Pole Socket  
**AM3-C-14-1** 1Gang 2 Way Switch +3 Pole Socket  
**AM3-C-15** 1Gang 1 Way Switch +Double 2 Pin Socket  
**AM3-C-15-1** 1Gang 2 Way Switch +Double 2 Pin Socket



**AM3-C-16** 1Gang 1 Way Switch +MF Socket  
**AM3-C-16-1** 1Gang 2 Way Switch +MF Socket  
**AM3-C-17** Double 3 Pole Socket  
**AM3-C-18** Double 2 Pin Socket  
**AM3-C-19** Double Thailand 3 Pole Socket  
**AM3-C-20** 2 MF Socket



**AM3-C-21** 1Gang 1 Way Switch + 13A Socket  
**AM3-C-21-1** 1Gang 2 Way Switch + 13A Socket  
**AM3-C-22** 1Gang 1 Way Switch +Double 3 Pole Socket  
**AM3-C-22-1** 1Gang 2 Way Switch +Double 3 Pole Socket  
**AM3-C-23** Triple 3 Pole Socket  
**AM3-C-24** 1Gang 1 Way Switch +2 Brazil Socket  
**AM3-C-24-1** 1Gang 2 Way Switch +2 Brazil Socket  
**AM3-C-25** Triple 2 Pin Socket



**AM3-C-26** 1Gang 1 Way Switch + Double 2 Pin Socket  
**AM3-C-26-1** 1Gang 2 Way Switch + Double 2 Pin Socket  
**AM3-C-27** 1Gang 1 Way Switch + 2 Italian Socket  
**AM3-C-27-1** 1Gang 2 Way Switch + 2 Italian Socket  
**AM3-C-28** 2 MF Socket  
**AM3-C-29** 2\*13A Socket  
**AM3-C-30** Thailand 3 Pole+USB Socket



**AM3-C-31** MF+USB Socket  
**AM3-C-32** 3 Pole+USB Socket  
**AM3-C-33** 3 Pole Socket+Double USB  
**AM3-C-34** Double Thailand 3 Pole Socket+2USB  
**AM3-C-35** Double 3 Pole Socket +2USB



**AM3-C-36** 13A Socket  
**AM3-C-37** 1Gang 1 Way Switch and Indicator light+2 Pin Socket  
**AM3-C-37-1** 1Gang 2 Way Switch and Indicator light+2 Pin Socket  
**AM3-C-38** 20A  
**AM3-C-39** 16A Germany Socket  
**AM3-C-40** Double USB +16A Germany Socket



**AM3-C-41** TV  
**AM3-C-42** TEL Socket  
**AM3-C-42-1** Computer Socket  
**AM3-C-43** Satellite Socket  
**AM3-C-44** Dimmer Switch  
**AM3-C-44-1** Speed Control Switch  
**AM3-C-45** Voice Control Switch  
**AM3-C-45-1** Touch Switch



# AM3-C

PC Material Panel

☐ Switch socket    Ⓞ life Electrical

## SWITCH SOCKET



**AM3-C-1**  
1Gang 1 Way Switch  
**AM3-C-1-1**  
1Gang 2 Way Switch



**AM3-C-2**  
1Gang 1 Way Switch  
**AM3-C-2-1**  
1Gang 2 Way Switch



**AM3-C-3**  
2Gang 1 Way Switch  
**AM3-C-3-1**  
2Gang 2 Way Switch



**AM3-C-4**  
3Gang 1 Way Switch  
**AM3-C-4-1**  
3Gang 2 Way Switch



**AM3-C-5**  
4Gang 1 Way Switch  
**AM3-C-5-1**  
4Gang 2 Way Switch



**AM3-C-6**  
Door Bell Switch



**AM3-C-7**  
15A/125V




**AM3-C-8**  
MF Socket




**AM3-C-9**  
3 Pole Socket



**AM3-C-10**  
Thailand 3 Pole Socket



**AM3-C-11**  
Double 2 Pin Socket



**AM3-C-12**  
8 Pin Socket



**AM3-C-13**  
1Gang 1 Way Switch  
+Thailand Socket

**AM3-C-13-1**  
1Gang 2 Way Switch  
+Thailand Socket



**AM3-C-14**  
1Gang 1 Way Switch  
+3 Pole Socket

**AM3-C-14-1**  
1Gang 2 Way Switch  
+3 Pole Socket



**AM3-C-15**  
1Gang 1 Way Switch  
+Double 2 Pin Socket

**AM3-C-15-1**  
1Gang 2 Way Switch  
+Double 2 Pin Socket



**AM3-C-21**  
1Gang 1 Way Switch  
+ 13A Socket

**AM3-C-21-1**  
1Gang 2 Way Switch  
+ 13A Socket



**AM3-C-22**  
1Gang 1 Way Switch  
+Double 3 Pole Socket

**AM3-C-22-1**  
1Gang 2 Way Switch  
+Double 3 Pole Socket



**AM3-C-23**  
Triple 3 Pole Socket



**AM3-C-24**  
1Gang 1 Way Switch  
+2 Brazil Socket

**AM3-C-24-1**  
1Gang 2 Way Switch  
+2 Brazil Socket



**AM3-C-25**  
Triple 2 Pin Socket



**AM3-C-26**  
1Gang 1 Way Switch  
+ Double 2 Pin Socket

**AM3-C-26-1**  
1Gang 2 Way Switch  
+ Double 2 Pin Socket



**AM3-C-27**  
1Gang 1 Way Switch  
+ 2 Italian Socket

**AM3-C-27-1**  
1Gang 2 Way Switch  
+ 2 Italian Socket



**AM3-C-28**  
2 MF Socket



**AM3-C-29**  
2\*13A Socket



**AM3-C-30**  
Thailand 3 Pole+USB Socket



**AM3-C-31**  
MF+USB Socket



**AM3-C-32**  
3 Pole+USB Socket




**AM3-C-33**  
3 Pole Socket+Double USB



**AM3-C-34**  
Double Thailand 3 Pole  
Socket+2USB



**AM3-C-35**  
Double 3 Pole Socket  
+2USB




**AM3-C-36**  
13A Socket



**AM3-C-37**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket

**AM3-C-37-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket



**AM3-C-38**  
20A



**AM3-C-39**  
16A Germany Socket



**AM3-C-40**  
Double USB  
+16A Germany Socket



**AM3-C-16**  
1Gang 1 Way Switch  
+MF Socket

**AM3-C-16-1**  
1Gang 2 Way Switch  
+MF Socket



**AM3-C-17**  
Double 3 Pole Socket



**AM3-C-18**  
Double 2 Pin Socket



**AM3-C-19**  
Double Thailand 3 Pole  
Socket



**AM3-C-20**  
2 MF Socket



**AM3-C-41**  
TV



**AM3-C-42**  
TEL Socket

**AM3-C-42-1**  
Computer Socket



**AM3-C-43**  
Satellite Socket



**AM3-C-44**  
Dimmer Switch

**AM3-C-44-1**  
Speed Control Switch



**AM3-C-45**  
Voice Control Switch

**AM3-C-45-1**  
Touch Switch



**Ultra Thin**

**1.5°**

Ultra small swing angle

**2.5mm**

Ultra-short key travel

**6.5mm**

The overall thickness

**AM3-A**



WHITE



GOLD



GRAY



BLACK

Custom Color





# AM3-A

PC Material Panel

☐ Switch socket    Ⓢ life Electrical



**AM3-A-1**  
1Gang 1 Way Switch  
**AM3-A-1-1**  
1Gang 2 Way Switch

**AM3-A-2**  
1Gang 1 Way Switch  
**AM3-A-2-1**  
1Gang 2 Way Switch

**AM3-A-3**  
2Gang 1 Way Switch  
**AM3-A-3-1**  
2Gang 2 Way Switch

**AM3-A-4**  
3Gang 1 Way Switch  
**AM3-A-4-1**  
3Gang 2 Way Switch

**AM3-A-5**  
4Gang 1 Way Switch  
**AM3-A-5-1**  
4Gang 2 Way Switch



**AM3-A-6**  
Door Bell Switch

**AM3-A-7**  
2 Pin Socket

**AM3-A-8**  
MF Socket

**AM3-A-9**  
3 Pole Socket

**AM3-A-10**  
Thailand 3 Pole Socket



**AM3-A-11**  
Double 2 Pin Socket

**AM3-A-12**  
8 Pin Socket

**AM3-A-13**  
1Gang 1 Way Switch  
+Thailand Socket  
**AM3-A-13-1**  
1Gang 2 Way Switch  
+Thailand Socket

**AM3-A-14**  
1Gang 1 Way Switch  
+3 Pole Socket  
**AM3-A-14-1**  
1Gang 2 Way Switch  
+3 Pole Socket

**AM3-A-15**  
1Gang 1 Way Switch  
+Double 2 Pin Socket  
**AM3-A-15-1**  
1Gang 2 Way Switch  
+Double 2 Pin Socket



**AM3-A-16**  
1Gang 1 Way Switch  
+MF Socket  
**AM3-A-16-1**  
1Gang 2 Way Switch  
+MF Socket

**AM3-A-17**  
Double 3 Pole Socket

**AM3-A-18**  
Double 2 Pin Socket

**AM3-A-19**  
Double Thailand 3 Pole Socket

**AM3-A-20**  
2 MF Socket




**AM3-A-21**  
1Gang 1 Way Switch  
+ 13A Socket  
**AM3-A-21-1**  
1Gang 2 Way Switch  
+ 13A Socket

**AM3-A-22**  
1Gang 1 Way Switch  
+Double 3 Pole Socket  
**AM3-A-22-1**  
1Gang 2 Way Switch  
+Double 3 Pole Socket

**AM3-A-23**  
Triple 3 Pole Socket

**AM3-A-24**  
1Gang 1 Way Switch  
+2 Brazil Socket  
**AM3-A-24-1**  
1Gang 2 Way Switch  
+2 Brazil Socket

**AM3-A-25**  
Triple 2 Pin Socket



**AM3-A-26**  
1Gang 1 Way Switch  
+ Double 2 Pin Socket  
**AM3-A-26-1**  
1Gang 2 Way Switch  
+ Double 2 Pin Socket

**AM3-A-27**  
1Gang 1 Way Switch  
+ 2 Italian Socket  
**AM3-A-27-1**  
1Gang 2 Way Switch  
+ 2 Italian Socket

**AM3-A-28**  
2 MF Socket

**AM3-A-29**  
2\*13A Socket

**AM3-A-30**  
1 Thailand 3 Pole+USB Socket




**AM3-A-31**  
MF+USB Socket

**AM3-A-32**  
3 Pole+USB Socket

**AM3-A-33**  
3 Pole Socket+Double USB

**AM3-A-34**  
Double Thailand 3 Pole Socket+2USB

**AM3-A-35**  
Double 3 Pole Socket  
+2USB



**AM3-A-36**  
13A Socket

**AM3-A-37**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket  
**AM3-A-37-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket

**AM3-A-38**  
20A

**AM3-A-39**  
16A Germany Socket

**AM3-A-40**  
Double USB  
+16A Germany Socket



**AM3-A-41**  
TV

**AM3-A-42**  
TEL Socket  
**AM3-A-42-1**  
Computer Socket

**AM3-A-43**  
Satellite Socket

**AM3-A-44**  
Dimmer Switch  
**AM3-A-44-1**  
Speed Control Switch

**AM3-A-45**  
Voice Control Switch  
**AM3-A-45-1**  
Touch Switch

# AM3-A

PC Material Panel

☐ Switch socket    Ⓞ life Electrical

## SWITCH SOCKET



**AM3-A-1**  
1Gang 1 Way Switch  
**AM3-A-1-1**  
1Gang 2 Way Switch



**AM3-A-2**  
1Gang 1 Way Switch  
**AM3-A-2-1**  
1Gang 2 Way Switch



**AM3-A-3**  
2Gang 1 Way Switch  
**AM3-A-3-1**  
2Gang 2 Way Switch



**AM3-A-4**  
3Gang 1 Way Switch  
**AM3-A-4-1**  
3Gang 2 Way Switch



**AM3-A-5**  
4Gang 1 Way Switch  
**AM3-A-5-1**  
4Gang 2 Way Switch



**AM3-A-6**  
Door Bell Switch



**AM3-A-7**  
15A/125V



**AM3-A-8**  
MF Socket




**AM3-A-9**  
3 Pole Socket



**AM3-A-10**  
Thailand 3 Pole Socket



**AM3-A-11**  
Double 2 Pin Socket



**AM3-A-12**  
8 Pin Socket



**AM3-A-13**  
1Gang 1 Way Switch  
+Thailand Socket

**AM3-A-13-1**  
1Gang 2 Way Switch  
+Thailand Socket




**AM3-A-14**  
1Gang 1 Way Switch  
+3 Pole Socket

**AM3-A-14-1**  
1Gang 2 Way Switch  
+3 Pole Socket



**AM3-A-15**  
1Gang 1 Way Switch  
+Double 2 Pin Socket

**AM3-A-15-1**  
1Gang 2 Way Switch  
+Double 2 Pin Socket



**AM3-A-21**  
1Gang 1 Way Switch  
+ 13A Socket

**AM3-A-21-1**  
1Gang 2 Way Switch  
+ 13A Socket



**AM3-A-22**  
1Gang 1 Way Switch  
+Double 3 Pole Socket

**AM3-A-22-1**  
1Gang 2 Way Switch  
+Double 3 Pole Socket



**AM3-A-23**  
Triple 3 Pole Socket



**AM3-A-24**  
1Gang 1 Way Switch  
+2 Brazil Socket

**AM3-A-24-1**  
1Gang 2 Way Switch  
+2 Brazil Socket



**AM3-A-25**  
Triple 2 Pin Socket



**AM3-A-26**  
1Gang 1 Way Switch  
+ Double 2 Pin Socket

**AM3-A-26-1**  
1Gang 2 Way Switch  
+ Double 2 Pin Socket



**AM3-A-27**  
1Gang 1 Way Switch  
+ 2 Italian Socket

**AM3-A-27-1**  
1Gang 2 Way Switch  
+ 2 Italian Socket



**AM3-A-28**  
2 MF Socket



**AM3-A-29**  
2\*13A Socket



**AM3-A-30**  
1 Thailand 3 Pole+USB Socket



**AM3-A-31**  
MF+USB Socket



**AM3-A-32**  
3 Pole+USB Socket



**AM3-A-33**  
3 Pole Socket+Double USB



**AM3-A-34**  
Double Thailand 3 Pole  
Socket+2USB



**AM3-A-35**  
Double 3 Pole Socket  
+2USB



**AM3-A-16**  
1Gang 1 Way Switch  
+MF Socket

**AM3-A-16-1**  
1Gang 2 Way Switch  
+MF Socket



**AM3-A-17**  
Double 3 Pole Socket



**AM3-A-18**  
Double 2 Pin Socket




**AM3-A-19**  
Double Thailand 3 Pole  
Socket



**AM3-A-20**  
2 MF Socket



**AM3-A-41**  
TV



**AM3-A-42**  
TEL Socket  
**AM3-A-42-1**  
Computer Socket



**AM3-A-43**  
Satellite Socket




**AM3-A-44**  
Dimmer Switch  
**AM3-A-44-1**  
Speed Control Switch



**AM3-A-45**  
Voice Control Switch  
**AM3-A-45-1**  
Touch Switch



*Acrylic* / Art



**Ultra Thin**

1.5°

Ultra small swing angle

2.5mm


Ultra-short key travel

6.5mm


The overall thickness

**AM3-B**

Acrylic Crystal Panel



GOLD



GRAY



BLACK




PATTERN




# AM3-B

Acrylic Crystal Panel

Switch socket life Electrical



GOLD



GRAY



BLACK



PATTERN




**AM3-B-1**

1Gang 1 Way Switch

**AM3-B-1-1**

1Gang 2 Way Switch



**AM3-B-2**

1Gang 1 Way Switch

**AM3-B-2-1**

1Gang 2 Way Switch



**AM3-B-3**

2Gang 1 Way Switch

**AM3-B-3-1**

2Gang 2 Way Switch



**AM3-B-4**

3Gang 1 Way Switch

**AM3-B-4-1**

3Gang 2 Way Switch



**AM3-B-5**

4Gang 1 Way Switch

**AM3-B-5-1**

4Gang 2 Way Switch



**AM3-B-6**

Door Bell Switch



**AM3-B-7**

2 Pin Socket



**AM3-B-8**

MF Socket




**AM3-B-9**

3 Pole Socket




**AM3-B-10**

Thailand 3 Pole Socket




**AM3-B-11**

Double 2 Pin Socket



**AM3-B-12**

8 Pin Socket



**AM3-B-13**

1Gang 1 Way Switch  
+Thailand Socket

**AM3-B-13-1**

1Gang 2 Way Switch  
+Thailand Socket




**AM3-B-14**

1Gang 1 Way Switch  
+3 Pole Socket

**AM3-B-14-1**

1Gang 2 Way Switch  
+3 Pole Socket




**AM3-B-15**

1Gang 1 Way Switch  
+Double 2 Pin Socket

**AM3-B-15-1**

1Gang 2 Way Switch  
+Double 2 Pin Socket



**AM3-B-21**

1Gang 1 Way Switch  
+ 13A Socket

**AM3-B-21-1**

1Gang 2 Way Switch  
+ 13A Socket



**AM3-B-22**

1Gang 1 Way Switch  
+Double 3 Pole Socket

**AM3-B-22-1**

1Gang 2 Way Switch  
+Double 3 Pole Socket



**AM3-B-23**

Triple 3 Pole Socket




**AM3-B-24**

1Gang 1 Way Switch  
+2 Brazil Socket

**AM3-B-24-1**

1Gang 2 Way Switch  
+2 Brazil Socket



**AM3-B-25**

Triple 2 Pin Socket



**AM3-B-26**

1Gang 1 Way Switch  
+ Double 2 Pin Socket

**AM3-B-26-1**

1Gang 2 Way Switch  
+ Double 2 Pin Socket



**AM3-B-27**

1Gang 1 Way Switch  
+ 2 Italian Socket

**AM3-B-27-1**

1Gang 2 Way Switch  
+ 2 Italian Socket



**AM3-B-28**

2 MF Socket



**AM3-B-29**

2\*13A Socket



**AM3-B-30**

1 nailand 3 Pole+USB Socket



**AM3-B-31**

MF+USB Socket



**AM3-B-32**

3 Pole+USB Socket



**AM3-B-33**

3 Pole Socket+Double USB



**AM3-B-34**

Double Thailand 3 Pole  
Socket+2USB



**AM3-B-35**

Double 3 Pole Socket  
+2USB



**AM3-B-16**

1Gang 1 Way Switch  
+MF Socket

**AM3-B-16-1**

1Gang 2 Way Switch  
+MF Socket



**AM3-B-17**

Double 3 Pole Socket



**AM3-B-18**

Double 2 Pin Socket



**AM3-B-19**

Double Thailand 3 Pole  
Socket



**AM3-B-20**

2 MF Socket



**AM3-B-41**

TV



**AM3-B-42**

TEL Socket

**AM3-B-42-1**

Computer Socket



**AM3-B-43**

Satelite Socket



**AM3-B-44**

Dimmer Switch

**AM3-B-44-1**

Speed Control Switch



**AM3-B-45**

Voice Control Switch

**AM3-B-45-1**

Touch Switch



1.5°

Ultra small swing angle

2.5mm

Ultra-short key travel

6.5mm

The overall thickness

# AM3-D

## *Ultra Thin Plan*

SWITCH & SOCKET



Provide the global home with great idea and create a beautiful home,  
its electrical accessories not only excellent in function,  
but also add unlimited fun and personalized features for your living space,  
we brought together singularity with inspiration, will create a unique household environment for you.



Custom Color:



WHITE SILVER GOLD GRAY Black



# AM3-D

PC Material Panel

☐ Switch socket    Ⓢ life Electrical



**AM3-D-21**  
1Gang 1 Way Switch  
+ 13A Socket

**AM3-D-21-1**  
1Gang 2 Way Switch  
+ 13A Socket

**AM3-D-22**  
1Gang 1 Way Switch  
+Double 3 Pole Socket

**AM3-D-22-1**  
1Gang 2 Way Switch  
+Double 3 Pole Socket

**AM3-D-23**  
Triple 3 Pole Socket

**AM3-D-24**  
1Gang 1 Way Switch  
+2 Brazil Socket

**AM3-D-24-1**  
1Gang 2 Way Switch  
+2 Brazil Socket

**AM3-D-25**  
Triple 2 Pin Socket



**AM3-D-1**  
1Gang 1 Way Switch

**AM3-D-2**  
1Gang 1 Way Switch

**AM3-D-3**  
2Gang 1 Way Switch

**AM3-D-4**  
3Gang 1 Way Switch

**AM3-D-5**  
4Gang 1 Way Switch

**AM3-D-1-1**  
1Gang 2 Way Switch

**AM3-D-2-1**  
1Gang 2 Way Switch

**AM3-D-3-1**  
2Gang 2 Way Switch

**AM3-D-4-1**  
3Gang 2 Way Switch

**AM3-D-5-1**  
4Gang 2 Way Switch



**AM3-D-26**  
1Gang 1 Way Switch  
+ Double 2 Pin Socket

**AM3-D-26-1**  
1Gang 2 Way Switch  
+ Double 2 Pin Socket

**AM3-D-27**  
1Gang 1 Way Switch  
+ 2 Italian Socket

**AM3-D-27-1**  
1Gang 2 Way Switch  
+ 2 Italian Socket

**AM3-D-28**  
2 MF Socket

**AM3-D-29**  
2\*13A Socket

**AM3-D-30**  
1 nailand 3 Pole+USB Socket



**AM3-D-6**  
Door Bell Switch

**AM3-D-7**  
2 Pin Socket

**AM3-D-8**  
MF Socket

**AM3-D-9**  
3 Pole Socket

**AM3-D-10**  
Thailand 3 Pole Socket



**AM3-D-31**  
MF+USB Socket

**AM3-D-32**  
3 Pole+USB Socket

**AM3-D-33**  
3 Pole Socket+Double USB

**AM3-D-34**  
Double Thailand 3 Pole Socket+2USB

**AM3-D-35**  
Double 3 Pole Socket +2USB



**AM3-D-11**  
Double 2 Pin Socket

**AM3-D-12**  
8 Pin Socket

**AM3-D-13**  
1Gang 1 Way Switch  
+Thailand Socket

**AM3-D-13-1**  
1Gang 2 Way Switch  
+Thailand Socket

**AM3-D-14**  
1Gang 1 Way Switch  
+3 Pole Socket

**AM3-D-14-1**  
1Gang 2 Way Switch  
+3 Pole Socket

**AM3-D-15**  
1Gang 1 Way Switch  
+Double 2 Pin Socket

**AM3-D-15-1**  
1Gang 2 Way Switch  
+Double 2 Pin Socket



**AM3-D-36**  
13A Socket

**AM3-D-37**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket

**AM3-D-37-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket

**AM3-D-38**  
20A

**AM3-D-39**  
16A Germany Socket

**AM3-D-40**  
Double USB  
+16A Germany Socket



**AM3-D-16**  
1Gang 1 Way Switch  
+MF Socket

**AM3-D-16-1**  
1Gang 2 Way Switch  
+MF Socket

**AM3-D-17**  
Double 3 Pole Socket

**AM3-D-18**  
Double 2 Pin Socket

**AM3-D-19**  
Double Thailand 3 Pole Socket

**AM3-D-20**  
2 MF Socket



**AM3-D-41**  
TV

**AM3-D-42**  
TEL Socket

**AM3-D-42-1**  
Computer Socket

**AM3-D-43**  
Satelite Socket

**AM3-D-44**  
Dimmer Switch

**AM3-D-44-1**  
Speed Control Switch

**AM3-D-45**  
Voice Control Switch

**AM3-D-45-1**  
Touch Switch



**AM3-E**  
PC Material Panel



provide the global home with great idea and create a beautiful home,  
its electrical accessories not only excellent in function,  
but also add unlimited fun and personalized features for your living space,  
we brought together singularity with inspiration, will create a unique household environment for you.

*Modern* / *Beyond*



Custom Color:

- WHITE+SILVER
- WHITE+GOLD
- GOLD
- GRAY
- BLACK

# AM3-E PC Material Panel

Switch socket life Electrical



**AM3-E-21**  
1Gang 1 Way Switch  
+ 13A Socket  
**AM3-E-21-1**  
1Gang 2 Way Switch  
+ 13A Socket



**AM3-D-22**  
1Gang 1 Way Switch  
+Double 3 Pole Socket  
**AM3-E-22-1**  
1Gang 2 Way Switch  
+Double 3 Pole Socket



**AM3-E-23**  
Triple 3 Pole Socket



**AM3-E-24**  
1Gang 1 Way Switch  
+2 Brazil Socket  
**AM3-E-24-1**  
1Gang 2 Way Switch  
+2 Brazil Socket



**AM3-E-25**  
Triple 2 Pin Socket



**AM3-E-1**  
1Gang 1 Way Switch  
**AM3-E-1-1**  
1Gang 2 Way Switch



**AM3-E-2**  
1Gang 1 Way Switch  
**AM3-E-2-1**  
1Gang 2 Way Switch



**AM3-E-3**  
2Gang 1 Way Switch  
**AM3-E-3-1**  
2Gang 2 Way Switch



**AM3-E-4**  
3Gang 1 Way Switch  
**AM3-E-4-1**  
3Gang 2 Way Switch




**AM3-E-5**  
4Gang 1 Way Switch  
**AM3-E-5-1**  
4Gang 2 Way Switch




**AM3-E-26**  
1Gang 1 Way Switch  
+ Double 2 Pin Socket  
**AM3-E-26-1**  
1Gang 2 Way Switch  
+ Double 2 Pin Socket



**AM3-E-27**  
1Gang 1 Way Switch  
+ 2 Italian Socket  
**AM3-E-27-1**  
1Gang 2 Way Switch  
+ 2 Italian Socket



**AM3-E-28**  
2 MF Socket



**AM3-E-29**  
2\*13A Socket



**AM3-E-30**  
1 Thailand 3 Pole+USB Socket



**AM3-E-6**  
Door Bell Switch



**AM3-E-7**  
2 Pin Socket



**AM3-E-8**  
MF Socket



**AM3-E-9**  
3 Pole Socket



**AM3-E-10**  
Thailand 3 Pole Socket



**AM3-E-31**  
MF+USB Socket



**AM3-E-32**  
3 Pole+USB Socket



**AM3-E-33**  
3 Pole Socket+Double USB



**AM3-E-34**  
Double Thailand 3 Pole  
Socket+2USB



**AM3-E-35**  
Double 3 Pole Socket  
+2USB



**AM3-E-11**  
Double 2 Pin Socket



**AM3-E-12**  
8 Pin Socket



**AM3-E-13**  
1Gang 1 Way Switch  
+Thailand Socket  
**AM3-E-13-1**  
1Gang 2 Way Switch  
+Thailand Socket



**AM3-E-14**  
1Gang 1 Way Switch  
+3 Pole Socket  
**AM3-E-14-1**  
1Gang 2 Way Switch  
+3 Pole Socket



**AM3-E-15**  
1Gang 1 Way Switch  
+Double 2 Pin Socket  
**AM3-E-15-1**  
1Gang 2 Way Switch  
+Double 2 Pin Socket



**AM3-E-36**  
13A Socket



**AM3-E-37**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket  
**AM3-E-37-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket



**AM3-E-38**  
20A



**AM3-E-39**  
16A Germany Socket



**AM3-E-40**  
Double USB  
+16A Germany Socket



**AM3-E-16**  
1Gang 1 Way Switch  
+MF Socket  
**AM3-E-16-1**  
1Gang 2 Way Switch  
+MF Socket



**AM3-E-17**  
Double 3 Pole Socket



**AM3-E-18**  
Double 2 Pin Socket



**AM3-E-19**  
Double Thailand 3 Pole  
Socket



**AM3-E-20**  
2 MF Socket



**AM3-E-41**  
TV



**AM3-E-42**  
TEL Socket  
**AM3-E-42-1**  
Computer Socket



**AM3-E-43**  
Satelite Socket



**AM3-E-44**  
Dimmer Switch  
**AM3-E-44-1**  
Speed Control Switch



**AM3-E-45**  
Voice Control Switch  
**AM3-E-45-1**  
Touch Switch



# AM3-E

PC Material Panel

 Switch socket  life Electrical

## SWITCH SOCKET



**AM3-E-1**  
1Gang 1 Way Switch  
**AM3-E-1-1**  
1Gang 2 Way Switch



**AM3-E-2**  
1Gang 1 Way Switch  
**AM3-E-2-1**  
1Gang 2 Way Switch



**AM3-E-3**  
2Gang 1 Way Switch  
**AM3-E-3-1**  
2Gang 2 Way Switch



**AM3-E-4**  
3Gang 1 Way Switch  
**AM3-E-4-1**  
3Gang 2 Way Switch



**AM3-E-5**  
4Gang 1 Way Switch  
**AM3-E-5-1**  
4Gang 2 Way Switch



**AM3-E-6**  
Door Bell Switch



**AM3-E-7**  
15A/125V



**AM3-E-8**  
MF Socket



**AM3-E-9**  
3 Pole Socket



**AM3-E-10**  
Thailand 3 Pole Socket



**AM3-E-11**  
Double 2 Pin Socket



**AM3-E-12**  
8 Pin Socket



**AM3-E-13**  
1Gang 1 Way Switch  
+Thailand Socket  
**AM3-E-13-1**  
1Gang 2 Way Switch  
+Thailand Socket



**AM3-E-14**  
1Gang 1 Way Switch  
+3 Pole Socket  
**AM3-E-14-1**  
1Gang 2 Way Switch  
+3 Pole Socket



**AM3-E-15**  
1Gang 1 Way Switch  
+Double 2 Pin Socket  
**AM3-E-15-1**  
1Gang 2 Way Switch  
+Double 2 Pin Socket



**AM3-E-21**  
1Gang 1 Way Switch  
+ 13A Socket



**AM3-D-22**  
1Gang 1 Way Switch  
+Double 3 Pole Socket



**AM3-E-23**  
Triple 3 Pole Socket



**AM3-E-24**  
1Gang 1 Way Switch  
+2 Brazil Socket



**AM3-E-25**  
Triple 2 Pin Socket




**AM3-E-26**  
1Gang 1 Way Switch  
+ Double 2 Pin Socket



**AM3-E-27**  
1Gang 1 Way Switch  
+ 2 Italian Socket



**AM3-E-28**  
2 MF Socket



**AM3-E-29**  
2\*13A Socket



**AM3-E-30**  
Italian 3 Pole+USB Socket



**AM3-E-26-1**  
1Gang 2 Way Switch  
+ Double 2 Pin Socket




**AM3-E-27-1**  
1Gang 2 Way Switch  
+ 2 Italian Socket



**AM3-E-31**  
MF+USB Socket




**AM3-E-32**  
3 Pole+USB Socket



**AM3-E-33**  
3 Pole Socket+Double USB



**AM3-E-34**  
Double Thailand 3 Pole  
Socket+2USB



**AM3-E-35**  
Double 3 Pole Socket  
+2USB



**AM3-E-36**  
13A Socket



**AM3-E-37**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket



**AM3-E-38**  
20A



**AM3-E-39**  
16A Germany Socket



**AM3-E-40**  
Double USB  
+16A Germany Socket




**AM3-E-16**  
1Gang 1 Way Switch  
+MF Socket



**AM3-E-17**  
Double 3 Pole Socket



**AM3-E-18**  
Double 2 Pin Socket



**AM3-E-19**  
Double Thailand 3 Pole  
Socket



**AM3-E-20**  
2 MF Socket



**AM3-E-41**  
TV



**AM3-E-42**  
TEL Socket



**AM3-E-43**  
Satellite Socket



**AM3-E-44**  
Dimmer Switch



**AM3-E-45**  
Voice Control Switch

**AM3-E-16-1**  
1Gang 2 Way Switch  
+MF Socket

**AM3-E-42-1**  
Computer Socket

**AM3-E-44-1**  
Speed Control Switch

**AM3-E-45-1**  
Touch Switch



**AM4-A-16**  
1Gang 1 Way Switch +Thailand Socket  
**AM4-A-16-1**  
1Gang 2 Way Switch +Thailand Socket

**AM4-A-17**  
1Gang 1 Way Switch +3 Pole Socket  
**AM4-A-17-1**  
1Gang 2 Way Switch +3 Pole Socket

**AM4-A-18**  
1Gang 1 Way Switch +MF Socket  
**AM4-A-18-1**  
1Gang 2 Way Switch +MF Socket

**AM4-A-19**  
2 MF Socket

**AM4-A-20**  
2\*13A Socket



**AM4-A-21**  
Double 2 Pin Socket

**AM4-A-22**  
Double 3 Pole Socket

**AM4-A-23**  
Double Thailand 3 Pole Socket

**AM4-A-24**  
1Gang 1 Way Switch +Double 2 Pin Socket  
**AM4-A-24-1**  
1Gang 2 Way Switch +Double 2 Pin Socket

**AM4-A-25**  
1Gang 1 Way Switch +Double 3 Pole Socket  
**AM4-A-25-1**  
1Gang 2 Way Switch +Double 3 Pole Socket



**AM4-A-26**  
1Gang 1 Way Switch +2 Brazil Socket  
**AM4-A-26-1**  
1Gang 2 Way Switch +2 Brazil Socket

**AM4-A-27**  
Triple 2 Pin Socket

**AM4-A-28**  
Triple 3 Pole Socket

**AM4-A-29**  
6 Pole Socket + USB

**AM4-A-30**  
16A Germany Socket



**AM4-A-1**  
1Gang 1 Way Switch  
**AM4-A-1-1**  
1Gang 2 Way Switch

**AM4-A-2**  
1Gang 1 Way Switch  
**AM4-A-2-1**  
1Gang 2 Way Switch

**AM4-A-3**  
2Gang 1 Way Switch  
**AM4-A-3-1**  
2Gang 2 Way Switch

**AM4-A-4**  
3Gang 1 Way Switch  
**AM4-A-4-1**  
3Gang 2 Way Switch

**AM4-A-5**  
4Gang 1 Way Switch  
**AM4-A-5-1**  
4Gang 2 Way Switch



**AM4-A-31**  
1Gang 1 Way Switch +16A Germany Socket  
**AM4-A-31-1**  
1Gang 2 Way Switch +16A Germany Socket

**AM4-A-32**  
Thailand 3 Pole+USB Socket

**AM4-A-33**  
3 Pole+USB Socket

**AM4-A-34**  
1Gang 1 Way Switch and Indicator light+2 Pin Socket  
**AM4-A-34-1**  
1Gang 2 Way Switch and Indicator light+2 Pin Socket

**AM4-A-35**  
20-25A



**AM4-A-6**  
Door Bell Switch

**AM4-A-7**  
2 Pin Socket

**AM4-A-8**  
3 Pole Socket

**AM4-A-9**  
Thailand 3 Pole Socket

**AM4-A-10**  
2 MF Socket



**AM4-A-36**  
TV

**AM4-A-37**  
TEL Socket  
**AM4-A-37-1**  
Computer Socket

**AM4-A-38**  
Satelite Socket

**AM4-A-39**  
Dimmer Switch  
**AM4-A-39-1**  
Speed Control Switch

**AM4-A-40**  
Voice Control Switch  
**AM4-A-40-1**  
Touch Switch





## AM4-B

Provide the global home with great idea and create a beautiful home,  
its electrical accessories not only excellent in function,  
but also add unlimited fun and personalized features for your living space,  
we brought together singularity with inspiration, will create a unique household environment for you.



# AM4-B

## PC Material Panel


# SWITCH SOCKET




**AM4-B-21**  
1Gang 1 Way Switch  
**AM4-B-21-1**  
1Gang 2 Way Switch



**AM3-A-22**  
1Gang 1 Way Switch  
**AM4-B-22-1**  
1Gang 2 Way Switch



**AM4-B-23**  
2Gang 1 Way Switch  
**AM4-B-23-1**  
2Gang 2 Way Switch




**AM4-B-24**  
3Gang 1 Way Switch  
**AM4-B-24-1**  
3Gang 2 Way Switch



**AM4-B-25**  
4Gang 1 Way Switch  
**AM4-B-25-1**  
4Gang 2 Way Switch



**AM4-B-1**  
1Gang 1 Way Switch  
**AM4-B-1-1**  
1Gang 2 Way Switch



**AM4-B-2**  
2Gang 1 Way Switch  
**AM4-B-2-1**  
2Gang 2 Way Switch



**AM4-B-3**  
1Gang 1 Way Switch  
+ 2 Pin Socket  
**AM4-B-3-1**  
1Gang 2 Way Switch  
+ 2 Pin Socket



**AM4-B-4**  
1Gang 1 Way Switch  
+3 Pole Socket  
**AM4-B-4-1**  
1Gang 2 Way Switch  
+3 Pole Socket



**AM4-B-5**  
1Gang 1 Way Switch  
+ Italian Socket  
**AM4-B-5-1**  
1Gang 2 Way Switch  
+ Italian Socket




**AM4-B-26**  
Door Bell Switch



**AM4-B-27**  
2 Pin Socket



**AM4-B-28**  
3 Pole Socket




**AM4-B-29**  
Thailand 3 Pole Socket



**AM4-B-30**  
MF Socket




**AM4-B-6**  
Double 2 Pin Socket




**AM4-B-7**  
1Gang 1 Way Switch  
+Double 3 Pole Socket  
**AM4-B-7**  
1Gang 2 Way Switch  
+Double 3 Pole Socket



**AM4-B-8**  
1Gang 1 Way Switch  
+2 Brazil Socket  
**AM4-B-8**  
1Gang 2 Way Switch  
+2 Brazil Socket



**AM4-B-9**  
Triple 2 Pin Socket



**AM4-B-10**  
Triple 3 Pole Socket




**AM4-B-31**  
2 MF Socket




**AM4-B-32**  
1Gang 1 Way Switch  
+Thailand Socket  
**AM4-B-32-1**  
1Gang 2 Way Switch  
+Thailand Socket



**AM4-B-33**  
1Gang 1 Way Switch  
+3 Pole Socket  
**AM4-B-33-1**  
1Gang 2 Way Switch  
+3 Pole Socket



**AM4-B-34**  
1Gang 1 Way Switch  
+MF Socket  
**AM4-B-34-1**  
1Gang 2 Way Switch  
+MF Socket



**AM4-B-35**  
Double 2 Pin Socket




**AM4-B-11**  
6 Pole Socket  
+ USB



**AM4-B-12**  
16A Germany Socket



**AM4-B-13**  
1Gang 1 Way Switch  
+ 16A Germany Socket  
**AM4-B-13-1**  
1Gang 2 Way Switch  
+ 16A Germany Socket



**AM4-B-14**  
2 MF Socket



**AM4-B-15**  
2\*13A Socket




**AM4-B-36**  
Double 3 Pole Socket



**AM4-B-37**  
Double Thailand  
3 Pole Socket



**AM4-B-38**  
Thailand 3 Pole+USB Socket



**AM4-B-39**  
MF+USB Socket



**AM4-B-40**  
3 Pole+USB Socket



**AM4-B-16**  
TV



**AM4-B-17**  
TEL Socket  
**AM4-B-17-1**  
Computer Socket



**AM4-B-18**  
Satellite Socket



**AM4-B-19**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket  
**AM4-B-19-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket



**AM4-B-20**  
20-25A



**AM4-B-41**  
TV



**AM4-B-42**  
TEL Socket  
**AM4-B-42-1**  
Computer Socket



**AM4-B-43**  
Satellite Socket



**AM4-B-44**  
Dimmer Switch  
**AM4-B-44-1**  
Speed Control Switch




**AM4-B-45**  
Voice Control Switch  
**AM4-B-45-1**  
Touch Switch




# PC Material Panel

## AM4-C

art switch  
Fashion



<b>AM4-C-1</b> 1Gang 1 Way Switch	<b>AM4-C-2</b> 1Gang 1 Way Switch	<b>AM4-C-3</b> 2Gang 1 Way Switch	<b>AM4-C-4</b> 3Gang 1 Way Switch	<b>AM4-C-5</b> 4Gang 1 Way Switch
<b>AM4-C-1-1</b> 1Gang 2 Way Switch	<b>AM4-C-2-1</b> 1Gang 2 Way Switch	<b>AM4-C-3-1</b> 2Gang 2 Way Switch	<b>AM4-C-4-1</b> 3Gang 2 Way Switch	<b>AM4-C-5-1</b> 4Gang 2 Way Switch
<b>AM4-C-6</b> Door Bell Switch	<b>AM4-C-7</b> 2 Pin Socket	<b>AM4-C-8</b> 3 Pole Socket	<b>AM4-C-9</b> Thailand 3 Pole Socket	<b>AM4-C-10</b> 2 MF Socket



<b>AM4-C-16</b> 1Gang 1 Way Switch +Thailand Socket	<b>AM4-C-17</b> 1Gang 1 Way Switch +3 Pole Socket	<b>AM4-C-18</b> 1Gang 1 Way Switch +MF Socket	<b>AM4-C-19</b> 2 MF Socket	<b>AM4-C-20</b> 2*13A Socket
<b>AM4-C-16-1</b> 1Gang 2 Way Switch +Thailand Socket	<b>AM4-C-17-1</b> 1Gang 2 Way Switch +3 Pole Socket	<b>AM4-C-18-1</b> 1Gang 2 Way Switch +MF Socket		
<b>AM4-C-21</b> Double 2 Pin Socket	<b>AM4-C-22</b> Double 3 Pole Socket	<b>AM4-C-23</b> Double Thailand 3 Pole Socket	<b>AM4-C-24</b> 1Gang 1 Way Switch +Double 2 Pin Socket	<b>AM4-C-25</b> 1Gang 1 Way Switch +Double 3 Pole Socket
			<b>AM4-C-24-1</b> 1Gang 2 Way Switch +Double 2 Pin Socket	<b>AM4-C-25-1</b> 1Gang 2 Way Switch +Double 3 Pole Socket
<b>AM4-C-26</b> 1Gang 1 Way Switch +2 Brazil Socket	<b>AM4-C-27</b> Triple 2 Pin Socket	<b>AM4-C-28</b> Triple 3 Pole Socket	<b>AM4-C-29</b> 6 Pole Socket + USB	<b>AM4-C-30</b> 16A Germany Socket
<b>AM4-C-26-1</b> 1Gang 2 Way Switch +2 Brazil Socket				
<b>AM4-C-31</b> 1Gang 1 Way Switch + 16A Germany Socket	<b>AM4-C-32</b> Thailand 3 Pole+USB Socket	<b>AM4-C-33</b> 3 Pole+USB Socket	<b>AM4-C-34</b> 1Gang 1 Way Switch and Indicator light+2 Pin Socket	<b>AM4-C-35</b> 20-25A
<b>AM4-C-31-1</b> 1Gang 2 Way Switch + 16A Germany Socket			<b>AM4-C-34-1</b> 1Gang 2 Way Switch and Indicator light+2 Pin Socket	
<b>AM4-C-36</b> TV	<b>AM4-C-37</b> TEL Socket	<b>AM4-C-38</b> Satelite Socket	<b>AM4-C-39</b> Dimmer Switch	<b>AM4-C-40</b> Voice Control Switch
	<b>AM4-C-37-1</b> Computer Socket		<b>AM4-C-39-1</b> Speed Control Switch	<b>AM4-C-40-1</b> Touch Switch




**AM4-C-16**  
1Gang 1 Way Switch  
+Thailand Socket



**AM4-C-16-1**  
1Gang 2 Way Switch  
+Thailand Socket




**AM4-C-17**  
1Gang 1 Way Switch  
+3 Pole Socket



**AM4-C-17-1**  
1Gang 2 Way Switch  
+3 Pole Socket



**AM4-C-18**  
1Gang 1 Way Switch  
+MF Socket



**AM4-C-18-1**  
1Gang 2 Way Switch  
+MF Socket



**AM4-C-19**  
2 MF Socket



**AM4-C-20**  
2\*13A Socket



**AM4-C-21**  
Double 2 Pin Socket



**AM4-C-22**  
Double 3 Pole Socket



**AM4-C-23**  
Double Thailand  
3 Pole Socket




**AM4-C-24**  
1Gang 1 Way Switch  
+Double 2 Pin Socket



**AM4-C-25**  
1Gang 1 Way Switch  
+Double 3 Pole Socket



**AM4-C-26**  
1Gang 1 Way Switch  
+2 Brazil Socket



**AM4-C-26-1**  
1Gang 2 Way Switch  
+2 Brazil Socket



**AM4-C-27**  
Triple 2 Pin Socket



**AM4-C-28**  
Triple 3 Pole Socket



**AM4-C-29**  
6 Pole Socket  
+ USB



**AM4-C-30**  
16A Germany Socket



**AM4-C-1**  
1Gang 1 Way Switch



**AM4-C-2**  
1Gang 1 Way Switch




**AM4-C-3**  
2Gang 1 Way Switch




**AM4-C-4**  
3Gang 1 Way Switch




**AM4-C-5**  
4Gang 1 Way Switch




**AM4-C-1-1**  
1Gang 2 Way Switch




**AM4-C-2-1**  
1Gang 2 Way Switch



**AM4-C-3-1**  
2Gang 2 Way Switch



**AM4-C-4-1**  
3Gang 2 Way Switch




**AM4-C-5-1**  
4Gang 2 Way Switch



**AM4-C-31**  
1Gang 1 Way Switch  
+ 16A Germany Socket



**AM4-C-31-1**  
1Gang 2 Way Switch  
+ 16A Germany Socket




**AM4-C-32**  
Thailand 3 Pole+USB Socket



**AM4-C-33**  
3 Pole+USB Socket



**AM4-C-34**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket



**AM4-C-34-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket



**AM4-C-35**  
20-25A



**AM4-C-6**  
Door Bell Switch



**AM4-C-7**  
15A/125V



**AM4-C-8**  
3 Pole Socket



**AM4-C-9**  
Thailand 3 Pole Socket



**AM4-C-10**  
2 MF Socket



**AM4-C-36**  
TV



**AM4-C-37**  
TEL Socket



**AM4-C-37-1**  
Computer Socket



**AM4-C-38**  
Satellite Socket



**AM4-C-39**  
Dimmer Switch



**AM4-C-39-1**  
Speed Control Switch



**AM4-C-40**  
Voice Control Switch



**AM4-C-40-1**  
Touch Switch






# AM4-G

provide the global home with great idea and create a beautiful home, its electrical accessories not only excellent in function, but also add unlimited fun and personalized features for your living space, we brought together singularity with inspiration, will create a unique household environment for you.

art switch  
**Fashion**



- AM4-G-1**  
1Gang 1 Way Switch
- AM4-G-2**  
1Gang 1 Way Switch
- AM4-G-3**  
2Gang 1 Way Switch
- AM4-G-4**  
3Gang 1 Way Switch
- AM4-G-5**  
4Gang 1 Way Switch
- AM4-G-1-1**  
1Gang 2 Way Switch
- AM4-G-2-1**  
1Gang 2 Way Switch
- AM4-G-3-1**  
2Gang 2 Way Switch
- AM4-G-4-1**  
3Gang 2 Way Switch
- AM4-G-5-1**  
4Gang 2 Way Switch
- AM4-G-6**  
Door Bell Switch
- AM4-G-7**  
2 Pin Socket
- AM4-G-8**  
3 Pole Socket
- AM4-G-9**  
Thailand 3 Pole Socket
- AM4-G-10**  
2 MF Socket

- AM4-G-16**  
1Gang 1 Way Switch +Thailand Socket
- AM4-G-17**  
1Gang 1 Way Switch +3 Pole Socket
- AM4-G-18**  
1Gang 1 Way Switch +MF Socket
- AM4-G-19**  
2 MF Socket
- AM4-G-20**  
2\*13A Socket
- AM4-G-16-1**  
1Gang 2 Way Switch +Thailand Socket
- AM4-G-17-1**  
1Gang 2 Way Switch +3 Pole Socket
- AM4-G-18-1**  
1Gang 2 Way Switch +MF Socket
- AM4-G-21**  
Double 2 Pin Socket
- AM4-G-22**  
Double 3 Pole Socket
- AM4-G-23**  
Double Thailand 3 Pole Socket
- AM4-G-24**  
1Gang 1 Way Switch +Double 2 Pin Socket
- AM4-G-25**  
1Gang 1 Way Switch +Double 3 Pole Socket
- AM4-G-24-1**  
1Gang 2 Way Switch +Double 2 Pin Socket
- AM4-G-25-1**  
1Gang 2 Way Switch +Double 3 Pole Socket
- AM4-G-26**  
1Gang 1 Way Switch +2 Brazil Socket
- AM4-G-27**  
Triple 2 Pin Socket
- AM4-G-28**  
Triple 3 Pole Socket
- AM4-G-29**  
6 Pole Socket + USB
- AM4-G-30**  
16A Germany Socket
- AM4-G-26-1**  
1Gang 2 Way Switch +2 Brazil Socket
- AM4-G-31**  
1Gang 1 Way Switch + 16A Germany Socket
- AM4-G-32**  
Thailand 3 Pole+USB Socket
- AM4-G-31-1**  
1Gang 2 Way Switch + 16A Germany Socket
- AM4-G-33**  
3 Pole+USB Socket
- AM4-G-34**  
1Gang 1 Way Switch and Indicator light+2 Pin Socket
- AM4-G-35**  
20-25A
- AM4-G-34-1**  
1Gang 2 Way Switch and Indicator light+2 Pin Socket
- AM4-G-36**  
TV
- AM4-G-37**  
TEL Socket
- AM4-G-38**  
Satelite Socket
- AM4-G-39**  
Dimmer Switch
- AM4-G-40**  
Voice Control Switch
- AM4-G-37-1**  
Computer Socket
- AM4-G-39-1**  
Speed Control Switch
- AM4-G-40-1**  
Touch Switch



**AM4-H**  
Plastic brushed panel.



**AM4-H-16**  
1Gang 1 Way Switch +Thailand Socket

**AM4-H-17**  
1Gang 1 Way Switch +3 Pole Socket

**AM4-H-18**  
1Gang 1 Way Switch +MF Socket

**AM4-H-19**  
2 MF Socket

**AM4-H-20**  
2\*13A Socket

**AM4-H-16-1**  
1Gang 2 Way Switch +Thailand Socket

**AM4-H-17-1**  
1Gang 2 Way Switch +3 Pole Socket

**AM4-H-18-1**  
1Gang 2 Way Switch +MF Socket

**AM4-H-21**  
Double 2 Pin Socket

**AM4-H-22**  
Double 3 Pole Socket

**AM4-H-23**  
Double Thailand 3 Pole Socket

**AM4-H-24**  
1Gang 1 Way Switch +Double 2 Pin Socket

**AM4-H-25**  
1Gang 1 Way Switch +Double 3 Pole Socket

**AM4-H-24-1**  
1Gang 2 Way Switch +Double 2 Pin Socket

**AM4-H-25-1**  
1Gang 2 Way Switch +Double 3 Pole Socket

**AM4-H-26**  
1Gang 1 Way Switch +2 Brazil Socket

**AM4-H-27**  
Triple 2 Pin Socket

**AM4-H-28**  
Triple 3 Pole Socket

**AM4-H-29**  
6 Pole Socket + USB

**AM4-H-30**  
16A Germany Socket



**AM4-H-1**  
1Gang 1 Way Switch

**AM4-H-2**  
1Gang 1 Way Switch

**AM4-H-3**  
2Gang 1 Way Switch

**AM4-H-4**  
3Gang 1 Way Switch

**AM4-H-5**  
4Gang 1 Way Switch

**AM4-H-1-1**  
1Gang 2 Way Switch

**AM4-H-2-1**  
1Gang 2 Way Switch

**AM4-H-3-1**  
2Gang 2 Way Switch

**AM4-H-4-1**  
3Gang 2 Way Switch

**AM4-H-5-1**  
4Gang 2 Way Switch



**AM4-H-6**  
Door Bell Switch

**AM4-H-7**  
2 Pin Socket

**AM4-H-8**  
3 Pole Socket

**AM4-H-9**  
Thailand 3 Pole Socket

**AM4-H-10**  
2 MF Socket



**AM4-H-31**  
1Gang 1 Way Switch + 16A Germany Socket

**AM4-H-32**  
Thailand 3 Pole+USB Socket

**AM4-H-33**  
3 Pole+USB Socket

**AM4-H-34**  
1Gang 1 Way Switch and Indicator light+2 Pin Socket

**AM4-H-35**  
20-25A

**AM4-H-31-1**  
1Gang 2 Way Switch + 16A Germany Socket

**AM4-H-34-1**  
1Gang 2 Way Switch and Indicator light+2 Pin Socket

**AM4-H-36**  
TV

**AM4-H-37**  
TEL Socket

**AM4-H-38**  
Satelite Socket

**AM4-H-39**  
Dimmer Switch

**AM4-H-40**  
Voice Control Switch

**AM4-H-37-1**  
Computer Socket

**AM4-H-39-1**  
Speed Control Switch

**AM4-H-40-1**  
Touch Switch





# AM4-J

PC Material Panel

art switch  
**Fashion**



**AM4-J-1** 1Gang 1 Way Switch  
**AM4-J-1-1** 1Gang 2 Way Switch  
**AM4-J-2** 1Gang 1 Way Switch  
**AM4-J-2-1** 1Gang 2 Way Switch  
**AM4-J-3** 2Gang 1 Way Switch  
**AM4-J-3-1** 2Gang 2 Way Switch  
**AM4-J-4** 3Gang 1 Way Switch  
**AM4-J-4-1** 3Gang 2 Way Switch  
**AM4-J-5** 4Gang 1 Way Switch  
**AM4-J-5-1** 4Gang 2 Way Switch



**AM4-J-6** Door Bell Switch  
**AM4-J-7** 2 Pin Socket  
**AM4-J-8** 3 Pole Socket  
**AM4-J-9** Thailand 3 Pole Socket  
**AM4-J-10** 2 MF Socket



**AM4-J-16** 1Gang 1 Way Switch +Thailand Socket  
**AM4-J-16-1** 1Gang 2 Way Switch +Thailand Socket  
**AM4-J-17** 1Gang 1 Way Switch +3 Pole Socket  
**AM4-J-17-1** 1Gang 2 Way Switch +3 Pole Socket  
**AM4-J-18** 1Gang 1 Way Switch +MF Socket  
**AM4-J-18-1** 1Gang 2 Way Switch +MF Socket  
**AM4-J-19** 2 MF Socket  
**AM4-J-20** 2\*13A Socket



**AM4-J-21** Double 2 Pin Socket  
**AM4-J-22** Double 3 Pole Socket  
**AM4-J-23** Double Thailand 3 Pole Socket  
**AM4-J-24** 1Gang 1 Way Switch +Double 2 Pin Socket  
**AM4-J-25** 1Gang 1 Way Switch +Double 3 Pole Socket



**AM4-J-26** 1Gang 1 Way Switch +2 Brazil Socket  
**AM4-J-26-1** 1Gang 2 Way Switch +2 Brazil Socket  
**AM4-J-27** Triple 2 Pin Socket  
**AM4-J-28** Triple 3 Pole Socket  
**AM4-J-29** 6 Pole Socket + USB  
**AM4-J-30** 16A Germany Socket



**AM4-J-31** 1Gang 1 Way Switch + 16A Germany Socket  
**AM4-J-31-1** 1Gang 2 Way Switch + 16A Germany Socket  
**AM4-J-32** Thailand 3 Pole+USB Socket  
**AM4-J-33** 3 Pole+USB Socket  
**AM4-J-34** 1Gang 1 Way Switch and Indicator light+2 Pin Socket  
**AM4-J-34-1** 1Gang 2 Way Switch and Indicator light+2 Pin Socket  
**AM4-J-35** 20-25A




**AM4-J-36** TV  
**AM4-J-37** TEL Socket  
**AM4-J-37-1** Computer Socket  
**AM4-J-38** Satellite Socket  
**AM4-J-39** Dimmer Switch  
**AM4-J-39-1** Speed Control Switch  
**AM4-J-40** Voice Control Switch  
**AM4-J-40-1** Touch Switch




brushed  
panel.

AM4-S



<b>AM4-S-1</b> 1Gang 1 Way Switch	<b>AM4-S-2</b> 1Gang 1 Way Switch	<b>AM4-S-3</b> 2Gang 1 Way Switch	<b>AM4-S-4</b> 3Gang 1 Way Switch	<b>AM4-S-5</b> 4Gang 1 Way Switch
<b>AM4-S-1-1</b> 1Gang 2 Way Switch	<b>AM4-S-2-1</b> 1Gang 2 Way Switch	<b>AM4-S-3-1</b> 2Gang 2 Way Switch	<b>AM4-S-4-1</b> 3Gang 2 Way Switch	<b>AM4-S-5-1</b> 4Gang 2 Way Switch
<b>AM4-S-6</b> Door Bell Switch	<b>AM4-S-7</b> 2 Pin Socket	<b>AM4-S-8</b> 3 Pole Socket	<b>AM4-S-9</b> Thailand 3 Pole Socket	<b>AM4-S-10</b> 2 MF Socket



<b>AM4-S-16</b> 1Gang 1 Way Switch +Thailand Socket	<b>AM4-S-17</b> 1Gang 1 Way Switch +3 Pole Socket	<b>AM4-S-18</b> 1Gang 1 Way Switch +MF Socket	<b>AM4-S-19</b> 2 MF Socket	<b>AM4-S-20</b> 2*13A Socket
<b>AM4-S-16-1</b> 1Gang 2 Way Switch +Thailand Socket	<b>AM4-S-17-1</b> 1Gang 2 Way Switch +3 Pole Socket	<b>AM4-S-18-1</b> 1Gang 2 Way Switch +MF Socket		
<b>AM4-S-21</b> Double 2 Pin Socket	<b>AM4-S-22</b> Double 3 Pole Socket	<b>AM4-S-23</b> Double Thailand 3 Pole Socket	<b>AM4-S-24</b> 1Gang 1 Way Switch +Double 2 Pin Socket	<b>AM4-S-25</b> 1Gang 1 Way Switch +Double 3 Pole Socket
			<b>AM4-S-24-1</b> 1Gang 2 Way Switch +Double 2 Pin Socket	<b>AM4-S-25-1</b> 1Gang 2 Way Switch +Double 3 Pole Socket
<b>AM4-S-26</b> 1Gang 1 Way Switch +2 Brazil Socket	<b>AM4-S-27</b> Triple 2 Pin Socket	<b>AM4-S-28</b> Triple 3 Pole Socket	<b>AM4-S-29</b> 6 Pole Socket + USB	<b>AM4-S-30</b> 16A Germany Socket
<b>AM4-S-26-1</b> 1Gang 2 Way Switch +2 Brazil Socket				
<b>AM4-S-31</b> 1Gang 1 Way Switch + 16A Germany Socket	<b>AM4-J-32</b> Thailand 3 Pole+USB Socket	<b>AM4-S-33</b> 3 Pole+USB Socket	<b>AM4-S-34</b> 1Gang 1 Way Switch and Indicator light+2 Pin Socket	<b>AM4-S-35</b> 20-25A
<b>AM4-S-31-1</b> 1Gang 2 Way Switch +16A Germany Socket			<b>AM4-S-34-1</b> 1Gang 2 Way Switch and Indicator light+2 Pin Socket	
<b>AM4-S-36</b> TV	<b>AM4-S-37</b> TEL Socket	<b>AM4-S-38</b> Satelite Socket	<b>AM4-S-39</b> Dimmer Switch	<b>AM4-S-40</b> Voice Control Switch
	<b>AM4-S-37-1</b> Computer Socket		<b>AM4-S-39-1</b> Speed Control Switch	<b>AM4-S-40-1</b> Touch Switch



# AM4-F acrylic panel.



**AM4-F-16**  
1Gang 1 Way Switch  
+Thailand Socket

**AM4-F-16-1**  
1Gang 2 Way Switch  
+Thailand Socket



**AM4-F-17**  
1Gang 1 Way Switch  
+3 Pole Socket

**AM4-F-17-1**  
1Gang 2 Way Switch  
+3 Pole Socket



**AM4-F-18**  
1Gang 1 Way Switch  
+MF Socket

**AM4-F-18-1**  
1Gang 2 Way Switch  
+MF Socket



**AM4-F-19**  
2 MF Socket



**AM4-F-20**  
2\*13A Socket



**AM4-F-21**  
Double 2 Pin Socket



**AM4-F-22**  
Double 3 Pole Socket



**AM4-F-23**  
Double Thailand  
3 Pole Socket



**AM4-F-24**  
1Gang 1 Way Switch  
+Double 2 Pin Socket

**AM4-F-24-1**  
1Gang 2 Way Switch  
+Double 2 Pin Socket



**AM4-F-25**  
1Gang 1 Way Switch  
+Double 3 Pole Socket

**AM4-F-25-1**  
1Gang 2 Way Switch  
+Double 3 Pole Socket



**AM4-F-26**  
1Gang 1 Way Switch  
+2 Brazil Socket

**AM4-F-26-1**  
1Gang 2 Way Switch  
+2 Brazil Socket



**AM4-F-27**  
Triple 2 Pin Socket



**AM4-F-28**  
Triple 3 Pole Socket



**AM4-F-29**  
6 Pole Socket + USB



**AM4-F-30**  
16A Germany Socket



**AM4-F-1**  
1Gang 1 Way Switch

**AM4-F-1-1**  
1Gang 2 Way Switch



**AM4-F-2**  
1Gang 1 Way Switch

**AM4-F-2-1**  
1Gang 2 Way Switch



**AM4-F-3**  
2Gang 1 Way Switch

**AM4-F-3-1**  
2Gang 2 Way Switch



**AM4-F-4**  
3Gang 1 Way Switch

**AM4-S-4-1**  
3Gang 2 Way Switch



**AM4-F-5**  
4Gang 1 Way Switch

**AM4-F-5-1**  
4Gang 2 Way Switch



**AM4-F-31**  
1Gang 1 Way Switch  
+ 16A Germany Socket

**AM4-F-31-1**  
1Gang 2 Way Switch  
+ 16A Germany Socket



**AM4-F-32**  
Thailand 3 Pole+USB Socket



**AM4-F-33**  
3 Pole+USB Socket



**AM4-F-34**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket

**AM4-F-34-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket



**AM4-F-35**  
20-25A



**AM4-F-6**  
Door Bell Switch



**AM4-F-7**  
2 Pin Socket



**AM4-F-8**  
3 Pole Socket



**AM4-F-9**  
Thailand 3 Pole Socket



**AM4-F-10**  
2 MF Socket



**AM4-F-36**  
TV



**AM4-F-37**  
TEL Socket

**AM4-F-37-1**  
Computer Socket



**AM4-F-38**  
Satellite Socket



**AM4-F-39**  
Dimmer Switch

**AM4-F-39-1**  
Speed Control Switch




**AM4-F-40**  
Voice Control Switch

**AM4-F-40-1**  
Touch Switch



## AM4-E acrylic panel.

- |              |               |
|--------------|---------------|
| White panel  | Gold panel    |
| Mood panel   | Green panel   |
| Gray panel   | Magenta panel |
| Orange panel | Black panel   |






# AM4-E

PC Material Panel

 Switch socket  life Electrical



**AM4-E-1**  
1Gang 1 Way Switch  
**AM4-E-1-1**  
1Gang 2 Way Switch

**AM4-E-2**  
2Gang 1 Way Switch  
**AM4-E-2-1**  
2Gang 2 Way Switch

**AM4-E-3**  
1Gang 1 Way Switch  
+ 2 Pin Socket  
**AM4-E-3-1**  
1Gang 2 Way Switch  
+ 2 Pin Socket

**AM4-E-4**  
1Gang 1 Way Switch  
+ 3 Pole Socket  
**AM4-E-4-1**  
1Gang 2 Way Switch  
+ 3 Pole Socket

**AM4-E-5**  
1Gang 1 Way Switch  
+ Italian Socket  
**AM4-E-5-1**  
1Gang 2 Way Switch  
+ Italian Socket



**AM4-E-6**  
Double 2 Pin Socket

**AM4-E-7**  
1Gang 1 Way Switch  
+ Double 3 Pole Socket  
**AM4-E-7**  
1Gang 2 Way Switch  
+ Double 3 Pole Socket

**AM4-E-8**  
1Gang 1 Way Switch  
+ 2 Brazil Socket  
**AM4-E-8**  
1Gang 2 Way Switch  
+ 2 Brazil Socket

**AM4-E-9**  
Triple 2 Pin Socket

**AM4-E-10**  
Triple 3 Pole Socket



**AM4-E-11**  
6 Pole Socket + USB

**AM4-E-12**  
16A Germany Socket

**AM4-E-13**  
1Gang 1 Way Switch  
+ 16A Germany Socket  
**AM4-E-13-1**  
1Gang 2 Way Switch  
+ 16A Germany Socket

**AM4-E-14**  
2 MF Socket

**AM4-E-15**  
2\*13A Socket



**AM4-E-16**  
TV

**AM4-E-17**  
TEL Socket  
**AM4-E-17-1**  
Computer Socket

**AM4-E-18**  
Satellite Socket

**AM4-E-19**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket  
**AM4-E-19-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket

**AM4-E-20**  
20-25A



**AM4-E-21**  
1Gang 1 Way Switch  
**AM4-E-21-1**  
1Gang 2 Way Switch

**AM3-E-22**  
1Gang 1 Way Switch  
**AM4-E-22-1**  
1Gang 2 Way Switch

**AM4-E-23**  
2Gang 1 Way Switch  
**AM4-E-23-1**  
2Gang 2 Way Switch

**AM4-E-24**  
3Gang 1 Way Switch  
**AM4-E-24-1**  
3Gang 2 Way Switch

**AM4-E-25**  
4Gang 1 Way Switch  
**AM4-E-25-1**  
4Gang 2 Way Switch



**AM4-E-26**  
Door Bell Switch

**AM4-E-27**  
2 Pin Socket

**AM4-E-28**  
3 Pole Socket

**AM4-E-29**  
Thailand 3 Pole Socket

**AM4-E-30**  
MF Socket



**AM4-E-31**  
2 MF Socket

**AM4-E-32**  
1Gang 1 Way Switch  
+ Thailand Socket  
**AM4-E-32-1**  
1Gang 2 Way Switch  
+ Thailand Socket

**AM4-E-33**  
1Gang 1 Way Switch  
+ 3 Pole Socket  
**AM4-E-33-1**  
1Gang 2 Way Switch  
+ 3 Pole Socket

**AM4-E-34**  
1Gang 1 Way Switch  
+ MF Socket  
**AM4-E-34-1**  
1Gang 2 Way Switch  
+ MF Socket

**AM4-E-35**  
Double 2 Pin Socket



**AM4-E-36**  
Double 3 Pole Socket

**AM4-E-37**  
Double Thailand  
3 Pole Socket

**AM4-E-38**  
Thailand 3 Pole+USB Socket

**AM4-E-39**  
MF+USB Socket

**AM4-E-40**  
3 Pole+USB Socket



**AM4-E-41**  
TV

**AM4-E-42**  
TEL Socket  
**AM4-E-42-1**  
Computer Socket

**AM4-E-43**  
Satellite Socket

**AM4-E-44**  
Dimmer Switch  
**AM4-E-44-1**  
Speed Control Switch

**AM4-E-45**  
Voice Control Switch  
**AM4-E-45-1**  
Touch Switch

# AM4-K

PC Material Panel

# SWITCH SOCKET



**AM4-K-21**  
1Gang 1 Way Switch

**AM4-K-21-1**  
1Gang 2 Way Switch



**AM3-K-22**  
1Gang 1 Way Switch

**AM4-K-22-1**  
1Gang 2 Way Switch



**AM4-K-23**  
2Gang 1 Way Switch

**AM4-K-23-1**  
2Gang 2 Way Switch



**AM4-K-24**  
3Gang 1 Way Switch

**AM4-K-24-1**  
3Gang 2 Way Switch



**AM4-K-25**  
4Gang 1 Way Switch

**AM4-K-25-1**  
4Gang 2 Way Switch



**AM4-K-1**  
1Gang 1 Way Switch

**AM4-K-1-1**  
1Gang 2 Way Switch



**AM4-K-2**  
2Gang 1 Way Switch

**AM4-K-2-1**  
2Gang 2 Way Switch



**AM4-K-3**  
1Gang 1 Way Switch  
+ 2 Pin Socket

**AM4-K-3-1**  
1Gang 2 Way Switch  
+ 2 Pin Socket



**AM4-K-4**  
1Gang 1 Way Switch  
+ 3 Pole Socket

**AM4-K-4-1**  
1Gang 2 Way Switch  
+ 3 Pole Socket



**AM4-K-5**  
1Gang 1 Way Switch  
+ Italian Socket

**AM4-K-5-1**  
1Gang 2 Way Switch  
+ Italian Socket



**AM4-K-26**  
Door Bell Switch



**AM4-K-27**  
2 Pin Socket



**AM4-K-28**  
3 Pole Socket



**AM4-K-29**  
Thailand 3 Pole Socket



**AM4-K-30**  
MF Socket



**AM4-K-6**  
Double 2 Pin Socket



**AM4-K-7**  
1Gang 1 Way Switch  
+ Double 3 Pole Socket

**AM4-K-7**  
1Gang 2 Way Switch  
+ Double 3 Pole Socket



**AM4-K-8**  
1Gang 1 Way Switch  
+ 2 Brazil Socket

**AM4-K-8**  
1Gang 2 Way Switch  
+ 2 Brazil Socket



**AM4-K-9**  
Triple 2 Pin Socket



**AM4-K-10**  
Triple 3 Pole Socket



**AM4-K-31**  
2 MF Socket



**AM4-K-32**  
1Gang 1 Way Switch  
+ Thailand Socket

**AM4-K-32-1**  
1Gang 2 Way Switch  
+ Thailand Socket



**AM4-K-33**  
1Gang 1 Way Switch  
+ 3 Pole Socket

**AM4-K-33-1**  
1Gang 2 Way Switch  
+ 3 Pole Socket



**AM4-K-34**  
1Gang 1 Way Switch  
+ MF Socket

**AM4-K-34-1**  
1Gang 2 Way Switch  
+ MF Socket



**AM4-K-35**  
Double 2 Pin Socket



**AM4-K-11**  
6 Pole Socket + USB



**AM4-K-12**  
16A Germany Socket



**AM4-K-13**  
1Gang 1 Way Switch  
+ 16A Germany Socket


**AM4-K-13-1**  
1Gang 2 Way Switch  
+ 16A Germany Socket



**AM4-K-14**  
2 MF Socket



**AM4-K-15**  
2\*13A Socket



**AM4-K-36**  
Double 3 Pole Socket



**AM4-K-37**  
Double Thailand  
3 Pole Socket



**AM4-K-38**  
Thailand 3 Pole+USB Socket



**AM4-K-39**  
MF+USB Socket



**AM4-K-40**  
3 Pole+USB Socket



**AM4-K-16**  
TV



**AM4-K-17**  
TEL Socket  
**AM4-K-17-1**  
Computer Socket



**AM4-K-18**  
Satellite Socket



**AM4-K-19**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket  
**AM4-K-19-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket



**AM4-K-20**  
20-25A



**AM4-K-41**  
TV



**AM4-K-42**  
TEL Socket  
**AM4-K-42-1**  
Computer Socket



**AM4-K-43**  
Satellite Socket



**AM4-K-44**  
Dimmer Switch  
**AM4-K-44-1**  
Speed Control Switch



**AM4-K-45**  
Voice Control Switch  
**AM4-K-45-1**  
Touch Switch



AM4-K



brushed  
panel.



AM4-K

art switch  
**Fashion**

# AM4-K

## PC Material Panel


# SWITCH SOCKET




**AM4-K-21**  
1Gang 1 Way Switch



**AM3-K-22**  
1Gang 1 Way Switch



**AM4-K-23**  
2Gang 1 Way Switch



**AM4-K-24**  
3Gang 1 Way Switch



**AM4-K-25**  
4Gang 1 Way Switch

**AM4-K-21-1**  
1Gang 2 Way Switch

**AM4-K-22-1**  
1Gang 2 Way Switch


**AM4-K-23-1**  
2Gang 2 Way Switch

**AM4-K-24-1**  
3Gang 2 Way Switch

**AM4-K-25-1**  
4Gang 2 Way Switch




**AM4-K-1**  
1Gang 1 Way Switch




**AM4-K-2**  
2Gang 1 Way Switch



**AM4-K-3**  
1Gang 1 Way Switch  
+ 2 Pin Socket



**AM4-K-4**  
1Gang 1 Way Switch  
+ 3 Pole Socket



**AM4-K-5**  
1Gang 1 Way Switch  
+ Italian Socket




**AM4-K-26**  
Door Bell Switch



**AM4-K-27**  
2 Pin Socket



**AM4-K-28**  
3 Pole Socket



**AM4-K-29**  
Thailand 3 Pole Socket



**AM4-K-30**  
MF Socket

**AM4-K-1-1**  
1Gang 2 Way Switch

**AM4-K-2-1**  
2Gang 2 Way Switch

**AM4-K-3-1**  
1Gang 2 Way Switch  
+ 2 Pin Socket

**AM4-K-4-1**  
1Gang 2 Way Switch  
+ 3 Pole Socket

**AM4-K-5-1**  
1Gang 2 Way Switch  
+ Italian Socket




**AM4-K-6**  
Double 2 Pin Socket




**AM4-K-7**  
1Gang 1 Way Switch  
+ Double 3 Pole Socket




**AM4-K-8**  
1Gang 1 Way Switch  
+ 2 Brazil Socket



**AM4-K-9**  
Triple 2 Pin Socket




**AM4-K-10**  
Triple 3 Pole Socket



**AM4-K-31**  
2 MF Socket



**AM4-K-32**  
1Gang 1 Way Switch  
+ Thailand Socket



**AM4-K-33**  
1Gang 1 Way Switch  
+ 3 Pole Socket



**AM4-K-34**  
1Gang 1 Way Switch  
+ MF Socket



**AM4-K-35**  
Double 2 Pin Socket

**AM4-K-7**  
1Gang 2 Way Switch  
+ Double 3 Pole Socket

**AM4-K-8**  
1Gang 2 Way Switch  
+ 2 Brazil Socket

**AM4-K-9**  
Triple 2 Pin Socket

**AM4-K-10**  
Triple 3 Pole Socket

**AM4-K-32-1**  
1Gang 2 Way Switch  
+ Thailand Socket

**AM4-K-33-1**  
1Gang 2 Way Switch  
+ 3 Pole Socket

**AM4-K-34-1**  
1Gang 2 Way Switch  
+ MF Socket




**AM4-K-11**  
6 Pole Socket + USB



**AM4-K-12**  
16A Germany Socket



**AM4-K-13**  
1Gang 1 Way Switch  
+ 16A Germany Socket




**AM4-K-14**  
2 MF Socket



**AM4-K-15**  
2\*13A Socket




**AM4-K-36**  
Double 3 Pole Socket



**AM4-K-37**  
Double Thailand  
3 Pole Socket



**AM4-K-38**  
Thailand 3 Pole+USB Socket



**AM4-K-39**  
MF+USB Socket



**AM4-K-40**  
3 Pole+USB Socket

**AM4-K-13-1**  
1Gang 2 Way Switch  
+ 16A Germany Socket



**AM4-K-16**  
TV



**AM4-K-17**  
TEL Socket  
**AM4-K-17-1**  
Computer Socket



**AM4-K-18**  
Satellite Socket



**AM4-K-19**  
1Gang 1 Way Switch  
and Indicator light+2 Pin Socket  
**AM4-K-19-1**  
1Gang 2 Way Switch  
and Indicator light+2 Pin Socket



**AM4-K-20**  
20-25A



**AM4-K-41**  
TV



**AM4-K-42**  
TEL Socket  
**AM4-K-42-1**  
Computer Socket



**AM4-K-43**  
Satellite Socket




**AM4-K-44**  
Dimmer Switch  
**AM4-K-44-1**  
Speed Control Switch



**AM4-K-45**  
Voice Control Switch  
**AM4-K-45-1**  
Touch Switch
















# AM4-D

provide the global home with great idea and create a beautiful home, its electrical accessories not only excellent in function, but also add unlimited fun and personalized features for your living space, we brought together singularity with inspiration, will create a unique household environment for you.



				
<b>AM4-D-1</b> 1Gang 1 Way Switch	<b>AM4-D-2</b> 1Gang 1 Way Switch	<b>AM4-D-3</b> 2Gang 1 Way Switch	<b>AM4-D-4</b> 3Gang 1 Way Switch	<b>AM4-D-5</b> 4Gang 1 Way Switch
<b>AM4-D-1-1</b> 1Gang 2 Way Switch	<b>AM4-D-2-1</b> 1Gang 2 Way Switch	<b>AM4-C-3-1</b> 2Gang 2 Way Switch	<b>AM4-D-4-1</b> 3Gang 2 Way Switch	<b>AM4-C-5-1</b> 4Gang 2 Way Switch
				
<b>AM4-D-6</b> Door Bell Switch	<b>AM4-D-7</b> 15A/125V	<b>AM4-D-8</b> 3 Pole Socket	<b>AM4-D-9</b> Thailand 3 Pole Socket	<b>AM4-D-10</b> 2 MF Socket

				
<b>AM4-D-16</b> 1Gang 1 Way Switch +Thailand Socket	<b>AM4-D-17</b> 1Gang 1 Way Switch +3 Pole Socket	<b>AM4-D-18</b> 1Gang 1 Way Switch +MF Socket	<b>AM4-D-19</b> 2 MF Socket	<b>AM4-D-20</b> 2*13A Socket
<b>AM4-D-16-1</b> 1Gang 2 Way Switch +Thailand Socket	<b>AM4-D-17-1</b> 1Gang 2 Way Switch +3 Pole Socket	<b>AM4-D-18-1</b> 1Gang 2 Way Switch +MF Socket		
				
<b>AM4-D-21</b> Double 2 Pin Socket	<b>AM4-D-22</b> Double 3 Pole Socket	<b>AM4-D-23</b> Double Thailand 3 Pole Socket	<b>AM4-D-24</b> 1Gang 1 Way Switch +Double 2 Pin Socket	<b>AM4-D-25</b> 1Gang 1 Way Switch +Double 3 Pole Socket
			<b>AM4-D-24-1</b> 1Gang 2 way Switch +Double 2 Pin Socket	<b>AM4-D-25-1</b> 1Gang 2 Way Switch +Double 3 Pole Socket
				
<b>AM4-D-26</b> 1Gang 1 Way Switch +2 Brazil Socket	<b>AM4-D-27</b> Triple 2 Pin Socket	<b>AM4-D-28</b> Triple 3 Pole Socket	<b>AM4-D-29</b> 6 Pole Socket + USB	<b>AM4-D-30</b> 16A Germany Socket
<b>AM4-D-26-1</b> 1Gang 2 Way Switch +2 Brazil Socket				
				
<b>AM4-D-31</b> 1Gang 1 Way Switch + 16A Germany Socket	<b>AM4-D-32</b> Thailand 3 Pole+USB Socket	<b>AM4-D-33</b> 3 Pole+USB Socket	<b>AM4-D-34</b> 1Gang 1 Way Switch and Indicator light+2 Pin Socket	<b>AM4-D-35</b> 20-25A
<b>AM4-D-31-1</b> 1Gang 2 Way Switch + 16A Germany Socket			<b>AM4-D-34-1</b> 1Gang 2 Way Switch and Indicator light+2 Pin Socket	
				
<b>AM4-D-36</b> TV	<b>AM4-D-37</b> TEL Socket	<b>AM4-D-38</b> Satelite Socket	<b>AM4-D-39</b> Dimmer Switch	<b>AM4-D-40</b> Voice Control Switch
	<b>AM4-D-37-1</b> Computer Socket		<b>AM4-D-39-1</b> Speed Control Switch	<b>AM4-D-40-1</b> Touch Switch

